

# RVM, RVF, RVT, TVR, COV

## Fittings, Vacuum Tubes, Collars


### Fittings RVM, RVF, RVT

Barbed fittings used to connect the vacuum source to the vacuum tube to guarantee a rigid connection.


Material: **brass**

| Models   | D       | D1      | D2      | d* |
|----------|---------|---------|---------|----|
| RVM 1014 | G1/4"-M | -       | -       | 10 |
| RVM 1038 | G3/8"-M | -       | -       | 10 |
| RVM 1538 | G3/8"-M | -       | -       | 15 |
| RVM 1512 | G1/2"-M | -       | -       | 15 |
| RVM 2012 | G1/2"-M | -       | -       | 20 |
| RVM 2034 | G3/4"-M | -       | -       | 20 |
| RVF 1038 | G3/8"-F | -       | -       | 10 |
| RVF 1512 | G1/2"-F | -       | -       | 15 |
| RVF 2034 | G3/4"-F | -       | -       | 20 |
| RVT 1012 | -       | G1/2"-F | G3/8"-M | 10 |
| RVT 1534 | -       | G1/2"-F | G3/4"-M | 15 |


(\*) Inside diameter of the suitable pipe



RVM



RVF



RVT

### Vacuum Tubes TVR


Thanks to their rigid design and steel coil, they ensure there is no pressure loss on the vacuum network.

Colour: **Crystal**

| Models | inside Ø | outside Ø | r* |
|--------|----------|-----------|----|
| TVR 10 | 10       | 16        | 18 |
| TVR 15 | 15.5     | 22.5      | 30 |
| TVR 20 | 19.5     | 27.5      | 37 |

\*r: minimum curve fitting

TVR vacuum tubes hold a 90% vacuum with an ambient temperature of 86°F.



### Collars COV

Accessory to be used for attaching TVR type pipes to guarantee perfect sealing.

Material: **stainless steel**

| Models | Tube réf. | L |
|--------|-----------|---|
| COV 10 | TVR 10    | 7 |
| COV 15 | TVR 15    | 7 |
| COV 20 | TVR 20    | 7 |

Other dimensions and shapes on request.



Note: All dimensions are in mm