

RVM, RVF, RVT, TVR, COV

Fittings, Vacuum Tubes, Collars


Fittings RVM, RVF, RVT

Barbed fittings used to connect the vacuum source to the vacuum tube to guarantee a rigid connection.


Material: **brass**

Models	D	D1	D2	d*
RVM 1014	G1/4"-M	-	-	10
RVM 1038	G3/8"-M	-	-	10
RVM 1538	G3/8"-M	-	-	15
RVM 1512	G1/2"-M	-	-	15
RVM 2012	G1/2"-M	-	-	20
RVM 2034	G3/4"-M	-	-	20
RVF 1038	G3/8"-F	-	-	10
RVF 1512	G1/2"-F	-	-	15
RVF 2034	G3/4"-F	-	-	20
RVT 1012	-	G1/2"-F	G3/8"-M	10
RVT 1534	-	G1/2"-F	G3/4"-M	15


(*) Inside diameter of the suitable pipe



RVM



RVF



RVT

Vacuum Tubes TVR


Thanks to their rigid design and steel coil, they ensure there is no pressure loss on the vacuum network.

Colour: **Crystal**

Models	inside Ø	outside Ø	r*
TVR 10	10	16	18
TVR 15	15.5	22.5	30
TVR 20	19.5	27.5	37

*r: minimum curve fitting

TVR vacuum tubes hold a 90% vacuum with an ambient temperature of 30°C.



Collars COV

Accessory to be used for attaching TVR type pipes to guarantee perfect sealing.

Material: **stainless steel**

Models	Tube réf.	L
COV 10	TVR 10	7
COV 15	TVR 15	7
COV 20	TVR 20	7

Other dimensions and shapes on request.



Note: All dimensions are in mm